

JOHNNY G SPIRIT BIKE

SOFTWARE VERSION PROCEDURE



Ride to power bike and enter Maintenance Mode by pressing and holding the 3 forward keys (+, -, Play) simultaneously for 3 seconds.



Entering Maintenance Mode may happen on the 1st attempt or require several attempts. The method for entering Maintenance Mode will change after the next software update.



Once in Maintenance Mode, press **Play Key** and use **+ Key** to scroll to *DISPLAY TEST*.




Press **Play Key** to display this screen. Press **Play Key** again to clear the screen to black, then immediately press and hold down **Play key**.



The software version will appear.



After the next software update is installed, there will be a dedicated screen for Software Version and a new procedure for entering Maintenance Mode.



When determining the appropriate software to install, the required information is:

1. Metric (01) / English (02)
2. GFit Module Version (3.02, 4.02 or 4.03)



Follow the procedure for updating software in the **Software Update Procedure document**.